

365300 ECS REAR DRIVE SHAFT 68MM - HUDY SPRING STEEL™

The new ECS shaft was developed for XB4/XB2 cars as a direct replacement for the front CVD drive shaft.

It is very important to regularly service the shafts in order to increase the lifespan and maintain performance.

Before use, these steps **MUST** be followed:

1. Assemble the ECS drive shaft.
2. Use #106210 HUDY Graphite Grease to lubricate both drive shaft couplings.
3. Use medium-grade thread lock (e.g., Loctite™ 242) on both setscrews. Do not use too much threadlock as it may block the drive shaft.
4. Ensure that the ECS drive shaft moves freely.

