

## #321117 XB2 GRAPHITE CHASSIS & SIDE BRACES - SET

**ALTERNATIVE 1:**  
USE THE SHORT BRACE SPACER without  
the long L shaped upper brace.

**ALTERNATIVE 2:**  
USE THE L SHAPED UPPER BRACE  
without the graphite short brace spacer.  
**(INITIAL SETTING)**

Place the lowest graphite brace under the front composite chassis guard.

**ALTERNATIVE 2**  
Installation of the screw  
from UNDER THE BRACE.

### Orientation for STANDARD BATTERY PACK

Orientation for  
LOW BATTERY PACK

**— ALTERNATIVE 1**  
Installation of the screw from  
UNDER THE CHASSIS.  
(INITIAL SETTING)

## #321117 XB2 GRAPHITE CHASSIS & SIDE BRACES - SET

**ALTERNATIVE 1:**  
USE THE SHORT BRACE SPACER without  
the long L shaped upper brace.

**ALTERNATIVE 2:**  
USE THE L SHAPED UPPER BRACE  
without the graphite short brace spacer.  
**(INITIAL SETTING)**

Place the lowest graphite brace under the front composite chassis guard.

### ALTERNATIVE 2

Installation of the screw  
from UNDER THE BRACE.

### Orientation for STANDARD BATTERY PACK

Orientation for  
LOW BATTERY PACK

**— ALTERNATIVE 1**  
Installation of the screw from  
UNDER THE CHASSIS.  
(INITIAL SETTING)