



When using front long suspension arms with a low downstop setting and large caster setting, we suggest using the included modified front upper arms to prevent the steering plate from hitting the upper arm.

---

The modified front upper arms are not available as a spare part and in the rare case that you need a replacement, please purchase the standard front upper arms and modify them with a Dremel™ tool, making sure to take adequate safety precautions and wear safety glasses.

---

If you have any questions, please do not hesitate to contact XRAY at **info@teamxray.com** or visit our website at **www.teamxray.com** for news and updates.