



#305330 DRIVE SHAFT ECS 52MM - HUDY SPRING STEEL™

#305331 DRIVE SHAFT ECS 50MM - HUDY SPRING STEEL™

The new ECS shaft was developed for all T2/T3/T4 cars as a direct replacement for the front CVD drive shaft.

50mm is recommend for foam racing.

52mm is recommend for rubber racing.

It is very important to regularly service the shafts in order to increase the lifespan and maintain performance.

Before use, these steps MUST be followed:

1. Assemble the ECS drive shaft.
2. Use #106210 HUDY Graphite Grease to lubricate both drive shaft couplings.
3. Use medium-grade thread lock (e.g., Loctite™ 242) on both setscrews. Do not use too much threadlock as it may block the drive shaft.
4. Ensure that the ECS drive shaft moves freely.

