

XRAY XB2

TECH TIP

STEERING LINKS

To prevent the steering linkage to disconnect in crash you may use the optional univerall ball with backstop. Follow the instructions bellow.

OPTION PARTS

#363240 BALL UNIVERSAL 5.8MM WITH BACKSTOP (2)

#332660 COMPOSITE STEERING & SERVO BALL JOINT 5.8MM (4+2)

INSTRUCTION MANUAL / 5. FRONT SUSPENSION

2x



STEERING LINKS

NOTE ORIENTATION



#332660

#363240


RIGHT
THREAD

From kit

LEFT
THREAD

#332660

#363240



#332660

OPTION PARTS

#903316 HEX SCREW SFH M3x16 (10)

INSTRUCTION MANUAL / 5. FRONT SUSPENSION

2x



#903316

#903316



NOTE ORIENTATION



If you have any questions, please do not hesitate to contact XRAY at info@teamxray.com or visit our website at www.teamxray.com for news and updates.