



XRAY

#305392 DRIVE SHAFT PIN 2 X 10 WITH FLAT SPOT (2)

USING PINS WITH FLAT SPOTS IN THE CVD SHAFTS



To help prevent loosening of the setscrew from the CVD shaft, XRAY recommends using these new pins with flat spots. The flat spots allow the setscrew to better settle into the coupling.

2x

THREAD LOCK 

DO NOT OVERTIGHTEN 

 GRAPHITE GREASE (HUDY #106210)

 NOTE ORIENTATION

CUTAWAY VIEW

When inserting the setscrew into the coupling, make sure that you can see the flat spot of the pin so the setscrew settles on the pin properly.