



TECH TIP: ENGINE HOLES ENLARGEMENT



Most popular engines have a 37.8mm distance between mounting holes.



However some engines (for example, Picco) have a smaller distance (37mm). If your engine has the smaller distance between mounting holes, you need to enlarge the mounting holes (for example, make each hole ø0.2~0.4mm larger) to allow the engine to fit the engine mounts properly.