


XRAY B08

ALU CASTER BLOCKS


352294



IMPORTANT: Always use the same caster block on left and right.

ALU CASTER BLOCKS

#352216	10°	RIGHT	#352226	10°	LEFT
#352217	12°	RIGHT	#352227	12°	LEFT
#352218	14°	RIGHT	#352228	14°	LEFT
#352219	16°	RIGHT	#352229	16°	LEFT



TOTAL CASTER = C-HUB CASTER + KICK UP

C-Hub Caster	KICK-UP				
	8°	9°	10°	11°	12°
10°	18°	19°	★ 20°	21°	22°
12°	20°	21°	22°	23°	24°
14°	22°	23°	24°	25°	26°
16°	24°	25°	26°	27°	28°

★ XB808 basic setting