



AIR FILTER OIL INSTRUCTIONS

Apply the oil to the foam filter in a bag & then let it stand for an hour or so, the oil will cure or set but time is dependant on ambient temperature. Remove excess if required with a cloth then fit & use. The oil is designed to be a very low viscosity to make saturating the filter easier & more thorough. During the oiling process some oils will evaporate to then give a sticky feel to the foam where it is ready to use.

If you have any questions, please do not hesitate to contact XRAY at **info@teamxray.com** or visit our website at **www.teamxray.com** for news and updates.