


XRAY T3

20011
SPECS
1/10 LUXURY
ELECTRIC TOURING CAR
PRESTIGE
PURE RACING DESIGN
WORLD'S BEST



Designed for
LiPo

450
ELECTRIC CAR

INSTRUCTION MANUAL



BEFORE YOU START

The T3 is a high-competition, high-quality, 1/10-scale touring car intended for persons aged 16 years and older with previous experience building and operating RC model racing cars. This is not a toy; it is a precision racing model. This model racing car is not intended for use by beginners, inexperienced customers, or by children without direct supervision of a responsible, knowledgeable adult. If you do not fulfill these requirements, please return the kit in unused and unassembled form back to the shop where you have purchased it.

Before building and operating your T3, **YOU MUST** read through all of the operating instructions and instruction manual and fully understand them to get

CUSTOMER SUPPORT

We have made every effort to make these instructions as easy to understand as possible. However, if you have any difficulties, problems, or questions, please do not hesitate to contact the XRAY support team at info@teamxray.com. Also, please visit our Web site at www.teamxray.com to find the latest updates, set-up information, option parts, and many other goodies. We pride ourselves on taking excellent care of our customers.

You can join thousands of XRAY fans and enthusiasts in our online community at:

www.teamxray.com

Failure to follow these instructions will be considered as abuse and/or neglect.

SAFETY PRECAUTIONS

Contains:

LEAD (CAS 7439-92-1) ANTIMONY (CAS 7440-36-0)

WARNING: This product contains a chemical known to the state of California to cause cancer and birth defects or other reproductive harm.

CAUTION: CANCER HAZARD

Contains lead, a listed carcinogen. Lead is harmful if ingested. Wash thoroughly after using. DO NOT use product while eating, drinking or using tobacco products. May cause chronic effects to gastrointestinal tract, CNS, kidneys, and blood. MAY CAUSE BIRTH DEFECTS.

When building, using and/or operating this model always wear protective glasses and gloves.

Take appropriate safety precautions prior to operating this model. You are responsible for this model's assembly and safe operation! Please read the instruction manual before building and operating this model and follow all safety precautions. Always keep the instruction manual at hand for quick reference, even after completing the assembly. Use only genuine and original authentic XRAY parts for maximum performance. Using any third party parts on this model will void guaranty immediately.

IMPORTANT NOTES - GENERAL

- This product is not suitable for children under 16 years of age without the direct supervision of a responsible and knowledgeable adult.
 - Carefully read all manufacturers warnings and cautions for any parts used in the construction and use of your model.
 - Assemble this kit only in places away from the reach of very small children.
 - First-time builders and users should seek advice from people who have building experience in order to assemble the model correctly and to allow the model to reach its performance potential.
 - Exercise care when using tools and sharp instruments.
 - Take care when building, as some parts may have sharp edges.
 - Keep small parts out of reach of small children. Children must not be allowed to put any parts in their mouth, or pull vinyl bag over their head.
 - Read and follow instructions supplied with paints and/or cement, if used (not included in kit).
 - Immediately after using your model, do NOT touch equipment on the model such as the motor and speed controller, because they generate high temperatures. You may seriously burn yourself seriously touching them.
 - Follow the operating instructions for the radio equipment at all times.
 - Do not put fingers or any objects inside rotating and moving parts, as this may cause damage or serious injury as your finger, hair, clothes, etc. may get caught.
 - Be sure that your operating frequency is clear before turning on or running your model, and never share the same frequency with somebody else at the same time. Ensure that others are aware of the operating frequency you are using and when you are using it.
 - Use a transmitter designed for ground use with RC cars. Make sure that no one else is using the same frequency as yours in your operating area. Using the same frequency at the same time, whether it is driving, flying or sailing, can cause loss of control of the RC model, resulting in a serious accident.
 - Always turn on your transmitter before you turn on the receiver in the car. Always turn off the receiver before turning your transmitter off.
 - Keep the wheels of the model off the ground when checking the operation of the radio equipment.
 - Disconnect the battery pack before storing your model.
 - When learning to operate your model, go to an area that has no obstacles that can damage your model if your model suffers a collision.
 - Remove any sand, mud, dirt, grass or water before putting your model away.
 - If the model behaves strangely, immediately stop the model, check and clear the problem.
 - To prevent any serious personal injury and/or damage to property, be responsible when operating all remote controlled models.
 - The model car is not intended for use on public places and roads or areas where its operation can conflict with or disrupt pedestrian or vehicular traffic.
 - Because the model car is controlled by radio, it is subject to radio interference from many sources that are beyond your control. Since radio interference can cause momentary loss of control, always allow a safety margin in all directions around the model in order to prevent collisions.
 - Do not use your model:
 - Near real cars, animals, or people that are unaware that an RC car is being driven.
 - In places where children and people gather
 - In residential districts and parks
 - In limited indoor spaces
 - In wet conditions
 - In the street
 - In areas where loud noises can disturb others, such as hospitals and residential areas.
 - At night or anytime your line of sight to the model may be obstructed or impaired in any way.
- To prevent any serious personal injury and/or damage to property, please be responsible when operating all remote controlled models.

the maximum enjoyment and prevent unnecessary damage. Read carefully and fully understand the instructions before beginning assembly.

Make sure you review this entire manual, the included set-up book, and examine all details carefully. If for some reason you decide The T3 is not what you wanted or expected, **do not continue any further**. Your hobby dealer cannot accept your T3 kit for return or exchange after it has been partially or fully assembled.

Contents of the box may differ from pictures. In line with our policy of continuous product development, the exact specifications of the kit may vary without prior notice.

XRAY Europe

K Vystavisku 6992
91101 Trenčín
Slovakia, EUROPE
Phone: 421-32-7401100
Fax: 421-32-7401109
E-mail: info@teamxray.com

XRAY USA

RCAmerica, 2970 Blystone Lane, Suite 109
Dallas, Texas 75220
USA
Phone: (800) 519-7221 * (214) 744-2400
Fax: (214) 744-2401
E-mail: xray@rcamerica.com

IMPORTANT NOTES - ELECTRICAL

- Insulate any exposed electrical wiring (using heat shrink tubing or electrical tape) to prevent dangerous short circuits. Take maximum care in wiring, connecting and insulating cables. Make sure cables are always connected securely. Check connectors for if they become loose. And if so, reconnect them securely. Never use R/C models with damaged wires. A damaged wire is extremely dangerous, and can cause short-circuits resulting in fire. Please have wires repaired at your local hobby shop.
- Low battery power will result in loss of control. Loss of control can occur due to a weak battery in either the transmitter or the receiver. Weak running battery may also result in an out of control car if your car's receiver power is supplied by the running battery. Stop operation immediately if the car starts to slow down.
- When not using RC model, always disconnect and remove battery.
- Do not disassemble battery or cut battery cables. If the running battery short-circuits, approximately 300W of electricity can be discharged, leading to fire or burns. Never disassemble battery or cut battery cables.
- Use a recommended charger for the receiver and transmitter batteries and follow the instructions correctly. Over-charging, incorrect charging, or using inferior chargers can cause the batteries to become dangerously hot.

Recharge battery when necessary. Continual recharging may damage battery and, in the worst case, could build up heat leading to fire. If battery becomes extremely hot during recharging, please ask your local hobby shop for check and/or repair and/or replacement.

- Regularly check the charger for potential hazards such as damage to the cable, plug, casing or other defects. Ensure that any damage is rectified before using the charger again. Modifying the charger may cause short-circuit or overcharging leading to a serious accident. Therefore do not modify the charger.
- Always unplug charger when recharging is finished.
- Do not recharge battery while battery is still warm. After use, battery retains heat. Wait until it cools down before charging.
- Do not allow any metal part to short circuit the receiver batteries or other electrical/electronic device on the model.
- Immediately stop running if your RC model gets wet as may cause short circuit.
- Please dispose of batteries responsibly. Never put batteries into fire.

R/C & BUILDING TIPS

- Make sure all fasteners are properly tightened. Check them periodically.
- Make sure that chassis screws do not protrude from the chassis.
- For the best performance, it is very important that great care is taken to ensure the free movement of all parts.
- Clean all ball-bearings so they move very easily and freely.
- Tap or pre-thread the plastic parts when threading screws.
- Self-tapping screws cut threads into the parts when being tightened. Do not use excessive force when tightening the self-tapping screws because you may strip out the thread in the plastic. We recommended you stop tightening a screw when you feel some resistance.
- Ask your local hobby shop for any advice.

Please support your local hobby shop. We at XRAY Model Racing Cars support all local hobby dealers. Therefore we ask you, if at all possible, to purchase XRAY products at your hobby dealer and give them your support like we do. If you have difficulty finding XRAY products, please check out www.teamxray.com to get advice, or contact us via email at info@teamxray.com, or contact the XRAY distributor in your country.

WARRANTY

XRAY guarantees this model kit to be free from defects in both material and workmanship within 30 days of purchase. The total monetary value under warranty will in no case exceed the cost of the original kit purchased. This warranty does not cover any components damaged by use or modification or as a result of wear. Part or parts missing from this kit must be reported within 30 days of purchase. No part or parts will be sent under warranty without proof of purchase. Should you find a defective or missing part, contact the local distributor. Service and customer support will be provided through local hobby store where you have purchased the kit, therefore make sure to purchase any XRAY products at your local hobby store. This model racing car is considered to be a high-performance racing vehicle. As such this vehicle will be used in an extreme range of conditions and situations, all which may cause premature wear or failure of any component. XRAY has no control over usage of vehicles once they leave the dealer, therefore XRAY can only offer warranty against all manufacturer's defects in materials, workmanship, and assembly at point of sale and before use. No warranties are expressed or implied that cover damage caused by what is considered normal use, or cover or imply how long any model cars' components or electronic components will last before requiring replacement.

Due to the high performance level of this model car you will need to periodically maintain and replace consumable components. Any and all warranty coverage will not cover replacement of any part or component damaged by neglect, abuse, or improper or unreasonable use. This includes but is not limited to

damage from crashing, chemical and/or water damage, excessive moisture, improper or no maintenance, or user modifications which compromise the integrity of components. Warranty will not cover components that are considered consumable on RC vehicles. XRAY does not pay nor refund shipping on any component sent to XRAY or its distributors for warranty. XRAY reserves the right to make the final determination of the warranty status of any component or part.

Limitations of Liability

XRAY makes no other warranties expressed or implied. XRAY shall not be liable for any loss, injury or damages, whether direct, indirect, special, incidental, or consequential, arising from the use, misuse, or abuse of this product and/or any product or accessory required to operate this product. In no case shall XRAY's liability exceed the monetary value of this product.

Take adequate safety precautions prior to operating this model. You are responsible for this model's assembly and safe operation.

Disregard of the any of the above cautions may lead to accidents, personal injury, or property damage. XRAY MODEL RACING CARS assumes no responsibility for any injury, damage, or misuse of this product during assembly or operation, nor any additions that may arise from the use of this product.

All rights reserved.

QUALITY CERTIFICATE

XRAY MODEL RACING CARS uses only the highest quality materials, the best compounds for molded parts and the most sophisticated manufacturing processes of TQM (Total Quality Management). We guarantee that all parts of a newly-purchased kit are manufactured with the highest regard to quality. However, due to the many factors inherent in model racecar competition, we cannot guarantee

any parts once you start racing the car. Products which have been worn out, abused, neglected or improperly operated will not be covered under warranty. We wish you enjoyment of this high-quality and high-performance RC car and wish you best success on the track!

In line with our policy of continuous product development, the exact specifications of the kit may vary. In the unlikely event of any problems with your new kit, you should contact the model shop where you purchased it, quoting the part number.

We do reserve all rights to change any specification without prior notice. All rights reserved.

CONTENTS

WARNINGS	2-3	4. STEERING	14-15
TOOLS AND ACCESSORIES	4	5. FRONT & REAR TRANSMISSION	16-20
0. KIT	5	6. SHOCK ABSORBERS	21-23
1. ALU BALL DIFF. & FRONT SOLID AXLE	6-7	7. FRONT & REAR ASSEMBLY	24-26
2. CENTRAL TRANSMISSION	8-10	7. FINAL ASSEMBLY	27-29
3. FRONT & REAR SUSPENSION	11-13	TECH TIPS & MULTI-FLEX TECHNOLOGY	30-31

SYMBOLS USED

Part bags used 	Assemble in the specified order 	Assemble left and right sides the same way 	Pay attention here 	Assemble as many times as specified (here twice) 	Apply thread lock 	Apply CA glue
Apply oil 	Apply grease 	Use pliers 	Ensure smooth non-binding movement 	Tighten screw gently 	<p>CORRECT </p> <p>WRONG </p> <p>Overtightened The threads are stripped.</p>	Follow Set-Up Book

TOOLS REQUIRED

HUDY TOOLS: Allen: 1.5mm, 2.0mm, 3.0mm Socket: 5.5mm, 7.0mm 	Combination Pliers (HUDY #189020) Snap Ring Pliers (HUDY #189040) 	Side Cutters (HUDY #189010) 	Hobby Knife Scissors (HUDY #188990) 	Turnbuckle 3mm, 4mm (HUDY #181030, HUDY #181040) 	Reamer (HUDY #107600)
---	--	---	---	--	-------------------------------------

EQUIPMENT INCLUDED

XRAY Premium Silicone Oil 350cSt (#359235) 	Diff. Grease (HUDY #106211) 	Graphite Grease (HUDY #106210)
---	--	---

EQUIPMENT REQUIRED

Transmitter 	Receiver 	Steering Servo 	Electric Motor & Pinion Gear and Setscrew 	Bearing Oil (HUDY #106230) 	Speed Controller
190mm Bodysell 	LiPo Battery 	Lexan Paint 	Battery Charger 	Fibre Tape (HUDY #107870) Double-sided Tape 	Wheels & Tires & Inserts

0. KIT (FACTORY PRE-ASSEMBLED)

COLOR INDICATIONS


At the beginning of each section is an exploded view of the parts to be assembled. There is also a list of all the parts and part numbers that are related to the assembly of that section.

The part descriptions are color-coded to make it easier for you to identify the source of a part. Here are what the different colors mean:

STYLE A - indicates parts that are included in the bag marked for the section.

STYLE B - indicates parts that were set aside in Section 0.

STYLE C - indicates parts that are already assembled from previous steps.



KIT


- 30 1131 T3'11 CHASSIS 2.5MM GRAPHITE
- 30 2027-O T3 ALU FRONT LOWER SUSP. ADJUST. BULKHEAD - ORANGE
- 30 3014-O T3 ALU RIGHT LAYSHAFT BULKHEAD - ORANGE
- 30 3022-O T3 ALU REAR LOWER SUSP. ADJUST. BULKHEAD - ORANGE

- 30 3052-O T3 ALU MOTOR MOUNT BULKHEAD - ORANGE
- 90 3306 HEX SCREW SFH M3x6 (10)

The XRAY T3 comes partially pre-assembled. Before starting assembly, disassemble the chassis parts, noting the position and orientation of the parts, particularly the bulkheads. Keep the parts, including the screw hardware, close at hand. In the assembly steps that follow, each section begins with a parts list. Parts indicated with **STYLE B** are from the previously disassembled chassis parts in section 0.


To protect and seal edges of graphite parts, sand edges smooth and then apply CA glue.

Do this for: chassis edges; filed battery slots, countersunk holes.





Apply only a bit of CA glue on the countersunk holes

1. ALU BALL DIFF. & FRONT SOLID AXLE




01.1 COMPOSITE SOLID AXLE

BAG	30 5003	ALU BALL DIFFERENTIAL 34T + 38T PULLEY - 7075 T6 - SET	30 5188	COMPOSITE SOLID AXLE 38T - SET
	30 5012-K	ALU T6 DIFF LONG OUTPUT SHAFT - HARD COATED - BLACK	90 2310	HEX SCREW SH M3x10 (10)
01.1	30 5022-K	ALU T6 DIFF SHORT OUTPUT SHAFT - HARD COATED - BLACK	93 0120	CARBIDE BALL 2.4 MM (12)
01.2	30 5040	SCREW FOR EXTERNAL DIFF ADJUSTMENT - SPRING STEEL	93 0138	CARBIDE BALL-BEARING AXIAL F3-8 3x8x3.5
	30 5058	DIFF PULLEY 38T WITH LABYRINTH DUST COVERS	93 0508	BALL-BEARING MR85ZZ 5x8x2.5 (2)
	30 5082	DIFF WASHER 17 x 23 x 1 (2)	94 1015	HIGH-SPEED BALL-BEARING 10x15x4 RUBBER SEALED (2)
	30 5105	XRAY MULTI-DIFF™ T3 LiPo (OPTION)	96 3030	CONE WASHER ST 3x8x0.5 (10)
	30 5135	COMPOSITE SOLID AXLE DRIVESHAFT ADAPTERS (2)	96 6080	CH-CLIP 8 (10)
	30 5136	ALU SOLID AXLE DRIVESHAFT ADAPTERS (2) (OPTION)		



1. ALU BALL DIFF. & FRONT SOLID AXLE



**DO NOT TIGHTEN THE DIFF COMPLETELY
THE DIFF MUST BE BROKEN IN PROPERLY !**

IMPORTANT: When you build the differential, do not tighten it fully initially; the differential needs to be broken in properly. When you build the diff tighten it very gently. When you put the diff in the car and complete the assembly, run the car for a few minutes, tighten the diff a little bit, and then recheck the diff. Repeat this process several times until you have the diff tightened to the point you want it. Final adjustments should ALWAYS be made with the diff in the car and on the track.


COMPOSITE FRONT SOLID AXLE



902310
SH M3x10




941015
BB 10x15x4



FRONT & REAR AXLES


#305003	ALU DIFF 34T + 38T PULLEY
#305105	XRAY ALU MULTI-DIFF™
#305188	COMPOSITE SOLID AXLE 38T PULLEY

CUTAWAY VIEW



FRONT & REAR AXLES

2. CENTRAL TRANSMISSION



BAG

02

- 30 2024-O T3 ALU UPPER CLAMP FOR BULKHEADS - ORANGE
- 30 2046-O T3 ALU LOWER SUSPENSION HOLDER - ORANGE
- 30 2069 T3 COMPOSITE LAYSHAFT BEARING SUPPORT SHIM (2)
- 30 2077 SET OF COMPOSITE HUBS + 1MM FOR BULKHEADS (4+2) (OPTION)
- 30 2078 SET OF COMPOSITE HUBS FOR BULKHEADS (4+2)
- 30 2087 SHOCK TOWER FRONT 3.0MM GRAPHITE - V2
- 30 3089 T3 SHOCK TOWER REAR 3.0MM GRAPHITE
- 30 5432 HIGH-PERFORMANCE KEVLAR DRIVE BELT FRONT 3 x 513 MM
- 30 5446 HIGH-PERFORMANCE KEVLAR DRIVE BELT REAR 3 x 189 MM
- 30 5521-K ALU SOLID LAYSHAFT - BLACK
- 30 5577 COMPOSITE FIXED PULLEY 20T (2)
- 30 5778 OFFSET SPUR GEAR 78T / 48 (OPTION)
- 30 5781 OFFSET SPUR GEAR 81T / 48 (OPTION)
- 30 5784 SPUR GEAR 84T / 48
- 30 5787 SPUR GEAR 87T / 48 (OPTION)
- 30 5862 OFFSET SPUR GEAR 92T / 64 (OPTION)
- 30 5866 OFFSET SPUR GEAR 96T / 64 (OPTION)
- 30 5870 OFFSET SPUR GEAR 100T / 64 (OPTION)
- 30 5874 OFFSET SPUR GEAR 104T / 64 (OPTION)
- 30 5876 OFFSET SPUR GEAR 106T / 64 (OPTION)
- 30 5878 OFFSET SPUR GEAR 108T / 64 (OPTION)
- 30 5880 OFFSET SPUR GEAR 110T / 64 (OPTION)

- 30 5882 OFFSET SPUR GEAR 112T / 64 (OPTION)
- 30 5884 OFFSET SPUR GEAR 114T / 64 (OPTION)
- 30 5886 OFFSET SPUR GEAR 116T / 64 (OPTION)
- 90 2304 HEX SCREW SH M3x4 - STAINLESS (10)
- 90 2306 HEX SCREW SH M3x6 (10)
- 90 3306 HEX SCREW SFH M3x6 (10)
- 94 0510 HIGH-SPEED BALL-BEARING 5x10x4 RUBBER SEALED (2)
- 96 5050 E-CLIP 5 (10)
- 98 1212 PIN 2x12 (10)


- 30 5003 ALU BALL DIFFERENTIAL 34T + 38T PULLEY - 7075 T6 - SET
- 30 5188 COMPOSITE SOLID AXLE 38T - SET

- 30 1131 T3'11 CHASSIS 2.5MM GRAPHITE
- 30 2027-O T3 ALU FRONT LOWER SUSP. ADJUST. BULKHEAD - ORANGE
- 30 3014-O T3 ALU RIGHT LAYSHAFT BULKHEAD - ORANGE
- 30 3022-O T3 ALU REAR LOWER SUSP. ADJUST. BULKHEAD - ORANGE
- 30 3052-O T3 ALU MOTOR MOUNT BULKHEAD - ORANGE
- 90 3306 HEX SCREW SFH M3x6 (10)

2. CENTRAL TRANSMISSION




903306
SFH M3x6



OPTIONAL FINE ROLL-CENTER ADJUSTMENT
Optional shims may be used for raising roll center. Use 3x7 shims with thicknesses between 0.1–0.5mm



The rear aluminum holders have integrated rear toe-in (approximately 1° rear toe-in).




902304
SH M3x4




965050
CS



981212
P 2x12



NOTE ORIENTATION
Only when using XRAY OFFSET spur gears



SPUR GEARS 48P	
#305778	OFFSET SPUR GEAR 78T / 48P
#305781	OFFSET SPUR GEAR 81T / 48P
#305784	SPUR GEAR 84T / 48P
#305787	SPUR GEAR 87T / 48P


SPUR GEARS 64P	
#305862	OFFSET SPUR GEAR 92T / 64P
#305866	OFFSET SPUR GEAR 96T / 64P
#305870	OFFSET SPUR GEAR 100T / 64P
#305874	OFFSET SPUR GEAR 104T / 64P
#305876	OFFSET SPUR GEAR 106T / 64P
#305878	OFFSET SPUR GEAR 108T / 64P
#305880	OFFSET SPUR GEAR 110T / 64P
#305882	OFFSET SPUR GEAR 112T / 64P
#305884	OFFSET SPUR GEAR 114T / 64P
#305886	OFFSET SPUR GEAR 116T / 64P



GEARING ADJUSTMENT



940510
BB 5x10x4




2. CENTRAL TRANSMISSION

FRONT BELT TENSION ADJUSTMENT

Front diff upper position is recommended for tight and technical carpet tracks. The upper diff position improves handling in chicanes as it provides more traction, increased steering and makes the car easier to drive.

Front diff lower position is recommended for large open asphalt tracks with long sweepers.

FRONT



INITIAL POSITION

PLACE TAB IN THIS BOTTOM NOTCH


TO LOOSEN FRONT BELT: Rotate both front nylon hubs in arrow direction (A)

TO TIGHTEN FRONT BELT: Rotate both front nylon hubs in arrow direction (B)

REAR BELT TENSION ADJUSTMENT

Rear diff upper position is recommended for tight and technical carpet tracks. The upper diff position improves handling in chicanes as it provides more traction, increased steering and makes the car easier to drive.

Rear diff lower position is recommended for large open asphalt tracks with long sweepers.



INITIAL POSITION

PLACE TAB IN THIS BOTTOM NOTCH


TO LOOSEN REAR BELT: Rotate both rear nylon hubs in arrow direction (A)

TO TIGHTEN REAR BELT: Rotate both rear nylon hubs in arrow direction (B)



OPTIONAL:
#303071 Belt Tensioner may be used when the front belt becomes worn and loose.

Upper Deck




DETAIL



903306
SH M3x6

2x

NOTE ORIENTATION




IMPORTANT!

Tighten the M3x6 screws carefully so the ball-bearing will move freely but without play.




REAR




902306
SH M3x6

L=R



FRONT


L=R




REAR



902306
SH M3x6




FRONT



REAR

3. FRONT & REAR SUSPENSION



BAG

03

- 30 2033-K ALU NUT FOR SUSPENSION HOLDER - BLACK (2)
- 30 2044 LOWER SUSPENSION HOLDERS (2+2+2)
- 30 2045-O T3 ALU LOWER SUSPENSION BLOCK - ORANGE
- 30 2047-O T3 ALU LOWER FRONT SUSPENSION 1-PIECE HOLDER - ORANGE
- 30 2163 FRONT SUSPENSION ARM - HARD - 1-HOLE
- 30 2164 FRONT SUSPENSION ARM - EXTRA-HARD - 1-HOLE (OPTION)
- 30 3059-K T3 MOTOR BULKHEAD HOLDER - BLACK
- 30 3129 COMPOSITE SET OF WHEELBASE SHIMS (3x1MM; 1x2MM) (2)
- 30 3134-K ALU SHIM FOR LOWER SUSP. HOLDER 3x7,5x1,5 - BLACK (10)
- 30 3163 REAR SUSPENSION ARM - HARD - 1-HOLE - V2
- 30 3164 REAR SUSPENSION ARM - EXTRA-HARD - 1-HOLE - V2 (OPTION)
- 30 7215 T2 FRONT SUSPENSION PIVOT PIN (2)
- 30 7314 T2'008 REAR SUSPENSION PIVOT PIN (2)



- 90 1308 HEX SCREW SB M3x8 (10)
- 90 1408 HEX SCREW SB M4x8 (10)
- 90 2314 HEX SCREW SH M3x14 (10)
- 90 2316 HEX SCREW SH M3x16 (10)
- 90 3306 HEX SCREW SFH M3x6 (10)



903306
SFH M3x6

OPTIONAL FINE ROLL-CENTER ADJUSTMENT


Optional shims may be used for raising roll center. Use 3x7 shims with thicknesses between 0.1-0.5mm



3. FRONT & REAR SUSPENSION




903306
SFH M3x6



901308
SB M3x8



901408
SB M4x8



OPTIONAL 2-HOLE REAR ARMS

Inner position - more rear traction
Outer position - more stable
Use the inner position for initial setting.

OPTIONAL REAR ARMS - 2-HOLE

#303165	HARD (H)
#303166	EXTRA-HARD (XH)

REAR ARMS

#303163	HARD (H)
#303164	EXTRA-HARD (XH)

HARD ARM - more rear traction (recommended for low-, medium-traction)
EXTRA HARD ARM - more steering (recommended for high-traction)




REAR DOWNSTOP
ADJUSTMENT
REAR ANTI-ROLL BAR



901308
SB M3x8



901408
SB M4x8



FRONT ARMS

#302163	HARD (H)
#302164	EXTRA-HARD (XH)

OPTIONAL FRONT ARMS - 2-HOLE

#302165	HARD (H)
#302166	EXTRA-HARD (XH)

OPTIONAL 2-HOLE FRONT ARMS

inner position - more steering
outer position - more stable
Use the outer position for initial setting.

HARD ARM - more steering (recommended for low-, medium-traction)
EXTRA HARD ARM - more stable, easier to drive (recommended for high-traction)



FRONT DOWNSTOP
ADJUSTMENT
FRONT ANTI-ROLL BAR

3. FRONT & REAR SUSPENSION



303129
SHIM 3x6x1



303129
SHIM 3x6x2



303134-K
SHIM 3x7.5x1.5






902314
SH M3x14



902316
SH M3x16



It is extremely important that the arms move freely on the pivot pins. If they do not, use the #107633 HUDY Arm Reamer to slightly resize the holes in the arms.



303129
SHIM 3x6x1




303134-K
SHIM 3x7.5x1.5



902316
SH M3x16




0mm




It is extremely important that the arms move freely on the pivot pins. If they do not, use the #107633 HUDY Arm Reamer to slightly resize the holes in the arms.

Use these suspension holders for initial assembly




4. STEERING



BAG


04

- | | | | |
|-----------|---|---------|---|
| 30 1192 | T3'11 UPPER DECK 2.0MM GRAPHITE | 30 2663 | COMPOSITE BALL JOINT 5 MM - OPEN - V2 (8) |
| 30 2506 | XRAY DUAL SERVO SAVER SET | 30 3129 | COMPOSITE SET OF SHIMS (3x1MM; 1x2MM) (2) |
| 30 2516 | COMPOSITE DUAL SERVO SAVER ARM (L+R) | 37 2502 | COMPOSITE SERVO SAVER - STIFF - SET |
| 30 2535 | ALU STEERING POST FOR DUAL SERVO SAVER (2) | | |
| 30 2545-O | ALU STEERING PLATE FOR DUAL SERVO SAVER - ORANGE | 90 2306 | HEX SCREW SH M3x6 (10) |
| 30 2610 | ADJ. TURNBUCKLE M3 L/R 40 MM - HUDY SPRING STEEL (2) (OPTION) | 90 3306 | HEX SCREW SFH M3x6 (10) |
| 30 2612 | ALU ADJ. TURNBUCKLE M3 L/R 39 MM - SWISS 7075 T6 (2) | 90 3308 | HEX SCREW SFH M3x8 (10) |
| 30 2630 | ADJ. TURNBUCKLE L/R 20 MM - HUDY SPRING STEEL (2) | 93 0306 | BALL-BEARING 3x6x2.5 (2) |
| 30 2652 | BALL END 5 MM WITH THREAD (2) | 94 0508 | HIGH-SPEED BALL-BEARING 5x8x2.5 RUBBER SEALED (2) |
| 30 2653 | BALL END 4.9MM WITH THREAD 6MM (2) | | |




- 303129 SHIM 3x6x1
- 903308 SFH M3x8
- 930306 BB 3x6
- 940508 BB 5x8

Use bearing oil for all bearings



Tighten the screws lightly but fully, and then loosen 1/3 turn so the composite dual servo saver moves freely.



TIP

To change Ackermann angle, use 2 identical shims (of same thickness) between the alu steering plate and ball end.

3x1mm & 1x2mm composite shims

4. STEERING

10

303129
SHIM 3x6x1

Use the shim so the servo saver does not touch the top deck. Shim thickness depends on servo type

NOTE: Servo position is also affected by these shims (between servo and stands).

USE ONLY THIS POSITION !

ASSEMBLY VIEW

H = Hitec
F = Futaba, Robe
K = KO, JR, Airtronics, Sanwa



902305
SH M3x5




902306
SH M3x6

TIP
Tech Tip for high-traction conditions
Page 30

SET-UP BOOK

ACKERMANN ADJUSTMENT
STEERING THROW SYMMETRY
CHASSIS FLEX SETTING
TOP DECK FLEX SETTING

5. FRONT & REAR TRANSMISSION



BAG


05

- | | | | |
|-----------|--|-----------|---|
| 30 2252 | COMPOSITE STEERING BLOCK - MEDIUM - V2 | 30 5231 | DRIVE SHAFT COUPLING - HUDY SPRING STEEL |
| 30 2253 | COMPOSITE STEERING BLOCK - HARD (OPTION) | 30 5241 | DRIVE SHAFT REPLACEMENT PLASTIC CAP 3.5 MM (4) |
| 30 2291 | STEEL STEERING BUSHING (2+2) | 30 5323 | DRIVE SHAFT 50MM - HUDY SPRING STEEL (OPTION) |
| 30 2363 | COMPOSITE C-HUB RIGHT - 4° DEG. - MEDIUM | 30 5324 | DRIVE SHAFT 52MM - HUDY SPRING STEEL |
| 30 2364 | COMPOSITE C-HUB LEFT - 4° DEG. - MEDIUM | 30 5325 | EQUALIZED CORNERING SPEED (ECS) DRIVE SHAFT 50MM (OPTION) |
| 30 2373 | COMPOSITE C-HUB RIGHT - 4° DEG. - HARD (OPTION) | 30 5326 | ALU DRIVE SHAFT SWISS 7075 T6 - HARD COATED - 52MM |
| 30 2374 | COMPOSITE C-HUB LEFT - 4° DEG. - HARD (OPTION) | 30 5327 | EQUALIZED CORNERING SPEED (ECS) DRIVE SHAFT 52MM (OPTION) |
| 30 2484 | ANTI-ROLL BAR FRONT 1.4 MM | 30 5328 | ALU DRIVE SHAFT SWISS 7075 T6 - HARD COATED - 50MM (OPTION) |
| 30 2663 | BALL JOINT 5 MM - OPEN - V2 (8) | 30 5341 | DRIVE AXLE - LIGHTWEIGHT - HUDY SPRING STEEL |
| 30 2664 | BALL JOINT 5 MM UNIDIRECTIONAL - OPEN (4) | 30 5350-K | ALU WHEEL HUB - BLACK (2) |
| 30 3032-O | ALU QUICK ROLL-CENTER HOLDER™ 4.9MM - O (OPTION) | 30 7221 | FRONT ARM PIVOT PIN (2) |
| 30 3033 | ALU QUICK ROLL-CENTER HOLDER 4.9MM - L1 + L2 | 30 7321 | REAR ARM PIVOT PIN (2) |
| 30 3122-K | ALU SHIM 3x6x1.0MM - BLACK (10) | 30 7455 | PIVOT BALL 5.0 MM DOUBLE BEVEL SHOULDERS (10) |
| 30 3123-K | ALU SHIM 3x6x2.0MM - BLACK (10) | 90 1302 | HEX SCREW SB M3x2.5 (10) |
| 30 3129 | COMPOSITE SET OF SHIMS (3x1MM; 1x2MM) (2) | 90 1303 | HEX SCREW SB M3x3 (10) |
| 30 3212 | ALU ADJ. TURNBUCKLE M3 L/R 26 MM - SWISS 7075 T6 (2) | 90 1304 | HEX SCREW SB M3x4 (10) |
| 30 3352 | UPRIGHT 0° OUTBOARD TOE-IN - MEDIUM | 90 1308 | HEX SCREW SB M3x8 (10) |
| 30 3353 | UPRIGHT 1° OUTBOARD TOE-IN - RIGHT - HARD (OPTION) | 90 2205 | HEX SCREW SH M2x5 (10) |
| 30 3363 | UPRIGHT 1° OUTBOARD TOE-IN - LEFT - HARD (OPTION) | 90 2306 | HEX SCREW SH M3x6 (10) |
| 30 3411 | COMPOSITE ANTI-ROLL BAR HOLDERS - V2 | 90 2310 | HEX SCREW SH M3x10 (10) |
| 30 3431-K | ALU 5 MM BALL END - BLACK (2) | 90 2314 | HEX SCREW SH M3x14 (10) |
| 30 3454 | BALL JOINT 5 MM - OPEN (4) | 94 0510 | HIGH-SPEED BALL-BEARING 5x10x4 RUBBER SEALED (2) |
| 30 3482 | ANTI-ROLL BAR REAR 1.2 MM | 98 0210 | PIN 2x10 (10) |

4x

901302
SB M3x2.5


980210
P 2x10



TIP

For easy and comfortable installation of the #305241 plastic caps use pliers as shown.

OPTIONAL ECS DRIVE SHAFTS



ECS shafts are available optionally in both 50mm and 52mm lengths. The ECS drive shafts were developed to decrease front wheel vibration when racing with a solid front axle, thus providing a much smoother and quieter ride and increased steering.

DRIVE SHAFTS

#305323	50MM - STEEL
#305324	52MM - STEEL
#305325	50MM - ECS
#305326	52MM - ALU
#305327	52MM - ECS
#305328	50MM - ALU

Longer drive shafts (52mm) make the car easier to drive because they give more traction and better stability, mainly in chicanes. However, the car will understeer more than with shorter (50mm) shafts which give a lot of steering and impart aggression to the car. You may also combine different lengths of shafts in front and rear (for example, using long shafts in the rear and short shafts in the front) depending on track conditions.

Both left & right shafts should ALWAYS be the same length at one end of the car (front or rear).

52mm shafts are recommended for carpet and big asphalt tracks

50mm shafts are recommended for small-medium tight asphalt tracks

IMPORTANT!

DO NOT use the plastic caps with composite solid axle included in the kits.

The new #305241 3.5mm plastic caps are for use ONLY with ALU ball diffs or the XRAY Multi-Diff™.

5. FRONT & REAR TRANSMISSION

902205
SH M2x5

940510
BB 5x10x4

980210
P 2x10

SET-UP BOOK

REAR TOE-IN ADJUSTMENT




UPRIGHTS	
#303351	1° - R - MEDIUM - 2-HOLE
#303352	0° - R/L - MEDIUM - 2-HOLE
#303353	1° - R - HARD - 2-HOLE
#303354	0° - R/L - HARD - 2-HOLE
#303361	1° - L - MEDIUM - 2-HOLE
#303362	0° - R/L - MEDIUM - 1-HOLE
#303363	1° - L - HARD - 2-HOLE
#303364	0° - R/L - HARD - 1-HOLE
#303358	ALU 1° - R/L - 4-HOLE
#303359	ALU 2° - R/L - 4-HOLE

902205
SH M2x5

940510
BB 5x10x4

980210
P 2x10

SET-UP BOOK




STEERING BLOCKS	
#302252	MEDIUM
#302253	HARD
#302256	ALU

WHEEL HUBS	
#305350	ALU - OFFSET 0 MM
#305351	ALU - OFFSET -0.75 MM
#305352	ALU - OFFSET +0.75 MM
#305353	ALU - OFFSET +1.5 MM

902310
SH M3x10

SET-UP BOOK



CASTER ADJUSTMENT



C-HUBS	
#302334	ALU 0° - R+L
#302335	ALU 2° - RIGHT
#302336	ALU 2° - LEFT
#302337	ALU 4° - RIGHT
#302338	ALU 4° - LEFT
#302339	ALU 6° - RIGHT
#302340	ALU 6° - LEFT
#302361	2° - RIGHT - MEDIUM
#302362	2° - LEFT - MEDIUM
#302363	4° - RIGHT - MEDIUM
#302364	4° - LEFT - MEDIUM
#302365	6° - RIGHT - MEDIUM
#302366	6° - LEFT - MEDIUM
#302371	2° - RIGHT - HARD
#302372	2° - LEFT - HARD
#302373	4° - RIGHT - HARD
#302374	4° - LEFT - HARD
#302375	6° - RIGHT - HARD
#302376	6° - LEFT - HARD

SET-UP BOOK

CAMBER ADJUSTMENT



5. FRONT & REAR TRANSMISSION



303123-K
SHIM 3x6x2



307455
PB 5mm



901304
SB M3x4



902306
SH M3x6



902314
SH M3x14

OPTIONAL 1-HOLE REAR UPRIGHTS

An optional 1-hole rear upright is available for fine tuning. This optional upright may be used on high-traction tracks or tracks with long sweepers, since the position of the center hole will allow faster driving through those corners because of better cornering speed.

DETAIL STEP 1

After you tighten the screw into the upright, pull the linkage upward so the ball joint "snaps" onto the pivot ball. The whole assembly should move freely.

POSITION

Use 2x alu shim 3x6x2mm on each side (total thickness = 4mm)

ALU SHIM 3x6x2mm

INITIAL POSITION
Use inner hole

TIGHTEN GENTLY

LEFT UPRIGHT = RIGHT UPRIGHT

0° OUTBOARD TOE-IN UPRIGHTS

54 mm

3x14mm

25 mm

1:1 2x

"CLICK"

TIGHTEN GENTLY



303122-K
SHIM 3x6x1



307455
PB 5mm



901304
SB M3x4



902306
SH M3x6



902314
SH M3x14

OPTIONAL 1-HOLE REAR UPRIGHTS

An optional 1-hole rear upright is available for fine tuning. This optional upright may be used on high-traction tracks or tracks with long sweepers, since the position of the center hole will allow faster driving through those corners because of better cornering speed.

POSITION

Use 2x alu shim 3x6x1mm on each side (total thickness = 2mm)

ALU SHIM 3x6x1mm

TIGHTEN GENTLY

LEFT UPRIGHT = RIGHT UPRIGHT

0° OUTBOARD TOE-IN UPRIGHTS

54 mm

3x14mm

23 mm

1:1 2x



5. FRONT & REAR TRANSMISSION

IO

303129
SHIM 3x6x2



307455
PB 5mm




902310
SH M3x10




ACKERMANN ADJUSTMENT

The number of shims changes the angle of the steering linkage. When is no shim used, car is easy to drive into the corner. The number of shims increases in-cornersteering but makes the car more difficult to drive.



901308
SB M3x8




901303
SB M3x3


901304
SB M3x4



902310
SH M3x10



ANTI-ROLL BARS
ADJUSTMENT



When the bars are set, verify that both sides move at the same time. If yes, the bars are set up correctly. If not, make sure that both downstops are the same and that the bar wire is flat.

5. FRONT & REAR TRANSMISSION



901303
SB M3x3





901304
SB M3x4



902310
SH M3x10

REAR ANTI-ROLL BAR




Initial position = **MIDDLE** ball

Use the **INNER** ball on low-traction tracks (mainly low-traction carpet tracks). The car will have more traction & more steering, but will be more difficult to drive because the car will roll more. Recommended on chicane tracks.

Use the **MIDDLE** ball on low- to medium-traction tracks (asphalt, carpet). The car will have a little less rear traction and the car will roll little less which will make it easier to drive with more cornering speed.

Use the **OUTER** ball on high-traction tracks (mainly high-traction asphalt tracks). The car will roll even less which will allow the use of more throttle in the corners, however the car will have less traction.

ASSEMBLY VIEW



Wire should be flush with end of pivot ball. 0mm


Only tighten enough to remove excessive free play; anti-roll bar must still move freely.



When the bars are set, verify that both sides move at the same time. If yes, the bars are set up correctly. If not, make sure that both downstops are the same and that the bar wire is flat.

SET-UP BOOK

ANTI-ROLL BARS ADJUSTMENT



FRONT

REAR


FRONT ANTI-ROLL BARS

#302482	FRONT 1.2 MM
#202483	FRONT 1.3 MM
#302484	FRONT 1.4 MM
#302485	FRONT 1.5 MM
#302486	FRONT 1.6 MM
#302488	FRONT 1.8 MM

REAR ANTI-ROLL BARS

#303481	REAR 1.1 MM
#303482	REAR 1.2 MM
#203483	REAR 1.3 MM
#303484	REAR 1.4 MM
#303485	REAR 1.5 MM
#303486	REAR 1.6 MM

6. SHOCK ABSORBERS



BAG

06

- | | | | |
|-----------|--|---------|--|
| 30 3241 | BALL UNIVERSAL 5.8 MM HEX (4) | 30 8390 | XRAY SELECTED ULTIMATE RACING SPRINGS (24) |
| 30 8035 | COMPOSITE PISTONS ADJUSTABLE + NON-ADJUST. (SET 2+6) | 30 8375 | XRAY SPRING-SET C=2.6 |
| 30 8040-O | SHOCK ADJ. NUT ALLU - ORANGE + O-RING (4+4) | 30 8377 | XRAY SPRING-SET C=3.0 |
| 30 8081 | SHOCK ABSORBER MEMBRANES - LOW (4) | 96 1032 | WASHER S 3.2 (10) |
| 30 8091 | SHOCK FOAM INSERTS - LOW (4) | 96 5019 | E-CLIP 1.9 (10) |
| 30 8302-O | XRAY SHOCK ABSORBER-SET 4-STEP - ORANGE - SHORT (2) | 96 5023 | E-CLIP 2.3 (10) |
| 30 8306-O | XRAY ALU SHOCK ABSORBER-SET - ORANGE (2) (OPTION) | 97 0050 | O-RING 5x1 (10) |
| 30 8316 | SHOCK BALL JOINT - OPEN (4) | 97 0121 | O-RING 12.1x1.6 (10) |
| 30 8331 | COMPOSITE FRAME SHOCK PARTS 4-STEP - SHORT - V2 | 97 1031 | SILICONE O-RING 3.1x1.6 (10) |
| 30 8352-O | ALU SHOCK CAP-NUT WITH VENT HOLE - ORANGE (2) | | |
| 30 8362 | HARDENED SHOCK SHAFT - SHORT (2) | | |
| 30 8380 | ADDITIONAL XRAY ULTIMATE RACING SPRINGS (20) | | |

ADJUSTABLE PISTONS

4x



Carefully remove the shock pistons from the frame, and remove all excess plastic flash

961032
S3.2

965019
C1.9

965023
C2.3

ADJUSTABLE PISTONS
INITIAL ASSEMBLY

4x




965019
C1.9

965023
C2.3

NON-ADJUSTABLE PISTONS


ALTERNATIVE

4x




6. SHOCK ABSORBERS

REBOUND ADJUSTMENT



REBOUND CHECK



After the shock is assembled you have to set the Shock Rebound.

1. Release the shock composite lower cap.
2. VERY SLOWLY do the following: Fully pull out the shock rod, push it back in fully, and then fully pull it out once more. Repeat this procedure the following number of times to achieve the desired Shock Rebound setting:
 10 times - approximately 75% rebound (high rebound - suggested for very low traction track)
 15 times - approximately 50% rebound (medium rebound - suggested for standard track)
 20 times - approximately 25% rebound (low rebound - suggested for very high traction track)


During the Rebound Adjustment procedure shock oil will leak out of the shock body through the O-ring on the shock rod... this is normal. During the Rebound Adjustment procedure DO NOT open the upper shock cap.

3. After you have set the Rebound Adjustment, re-install the shock lower composite cap.


4. Check the Shock Rebound setting by pushing the shock rod fully into the shock body, releasing it, and observing how far the shock rod extends by itself:
 * 25% out of the shock body (low rebound)
 * 50% out of the shock body (medium rebound)
 * 75% out of the shock body (high rebound).
 If the shock rod rebounds too much, return to Step 1 and repeat the procedure.

If the shock rod does not rebound enough, you will have to refill the shock with shock oil, and then repeat the bleeding and Shock Rebound procedures.

Cutaway view of assembled shock absorber



CHECK NEXT TECH TIP



Shock length adjustment:

It is VERY important that all shocks are equal length. Fully extend the shock absorber and measure the end-to-end length; we recommend using digital calipers to give an accurate measurement. If a shock absorber is shorter or longer than others, adjust the shock length by tightening or loosening the ball joint on the shock rod.

Damping adjustment:

If you built the adjustable shocks, fully extend the shock rod and turn it slightly to lock the piston in the shock body.

Turning the shock rod fully CCW aligns 4 holes in the pistons (softest damping). Turning the shock rod fully CW aligns 1 hole in the pistons (hardest damping). The shocks have four settings, each of which can be felt by a slight "click".

Set all four shocks initially to position 3 (3 holes open): turn fully CCW, then turn CW by 1 click.

2x FRONT SHOCKS (C=3.0 springs)

2x REAR SHOCKS (C=2.6 springs)



SET-UP BOOK
SHOCK DAMPING ADJUSTMENT
SPRING RATE SELECTION

TECH TIP

Follow this tech tip to properly install pivot balls into the top pivot and bottom ball joint.




- Parts Needed:
- M3 x 16 SH screw
 - M3 shim

Note that the composite parts have two sides, noticeable around the pivot ball hole: one side has a shiny finish, the other side has a regular finish.




Install pivot balls into top pivot or lower ball joint as shown, on the proper sides.

Note that the lower pivot ball has an extra shoulder.



7. FRONT & REAR ASSEMBLY



BAG

07

30 1202 COMPOSITE BUMPER
 30 1218 COMPOSITE UPPER HOLDER FOR BUMPER
 30 1324 FRONT BODY MOUNT SET +2MM HEIGHT

90 2306 HEX SCREW SH M3x6 (10)
 90 3308 HEX SCREW SFH M3x8 (10)
 90 3310 HEX SCREW SFH M3x10 (10)

96 0030 NUT M3 (10)
 98 1212 PIN 2x12 (10)

30 1222 FOAM BUMPER

30 8302 XRAY SHOCK ABSORBER-SET 4-STEP - SHORT (2)
 30 8306 XRAY ALU SHOCK ABSORBER-SET (2) (OPTION)




903308
SFH M3x8



903310
SFH M3x10




960030
N M3x10




7. FRONT & REAR ASSEMBLY


903308
SFH M3x8



981212
P 2x12



902306
SFH M3x6



308019 Set of Shock Shims & Nuts

TECH TIP:


To make the car more stable and easier to drive, move the front shocks forward. Stability increases mainly in chicanes. Note that the car will have less steering into corners.

- Upper mount (shock tower): Add a plastic nut and use a longer screw 3x8mm (NOT INCLUDED) to space the upper end of the shock away from the shock tower.
- Lower mount (lower arm): Add shims and use a longer setscrew 3x10mm (NOT INCLUDED) on the lower arms to space the lower end of the shock away from the arm.

FRONT SHOCK
C3.0 SPRING

SET-UP BOOK
SHOCK POSITION ADJUSTMENT
RIDE HEIGHT ADJUSTMENT
DROOP ADJUSTMENT


7. FRONT & REAR ASSEMBLY



BAG 	30 1334	REAR BODY MOUNT SET +2MM HEIGHT	98 1212	PIN 2x12 (10)
	90 2306	HEX SCREW SH M3x6 (10)	30 8302	XRAY SHOCK ABSORBER-SET 4-STEP - SHORT (2)
	90 2308	HEX SCREW SH M3x8 (10)	30 8306	XRAY ALU SHOCK ABSORBER-SET (2) (OPTION)

902308
 SH M3x8

981212
 P 2x12



902306
 SH M3x6

308019 Set of Shock Shims & Nuts

TECH TIP:
 To make the car more stable and easier to drive, move the rear shocks rearward. Stability increases mainly in chicanes. Note that the car will have less steering into corners.

- Upper mount (shock tower): Add a plastic nut and use a longer screw 3x8mm (NOT INCLUDED) to space the upper end of the shock away from the shock tower.
- Lower mount (lower arm): Add shims and use a longer setscrew 3x10mm (NOT INCLUDED) on the lower arms to space the lower end of the shock away from the arm.


OPTIONAL INITIAL POSITION

When using optional 2-hole arms and optional 1-hole rear upright, use the second hole from the bottom on the shock tower.

REAR SHOCK (C2 .6 SPRING)

SET-UP BOOK
 SHOCK POSITION ADJUSTMENT
 RIDE HEIGHT ADJUSTMENT
 DROOP ADJUSTMENT

7. FINAL ASSEMBLY



BAG

08

305912-306000 NARROW PINION GEAR ALU HARD COATED (OPTION)
 30 6163-K GRAPHITE BATTERY STRAP 6-CELL (SET) - BLACK - (OPTION)
 30 6184 LONG COMPOSITE LIPO BATTERY BACKSTOP (1+1)
 30 6200-K ALU SERVO MOUNT - BLACK (2)
 30 6219 COMPOSITE SET OF SERVO SHIMS (4)
 30 6301 ANTENNA MOUNT - THIN
 30 9402 BODY CLIP FOR 6MM BODY POST (4)

90 2306 HEX SCREW SH M3x6 (10)
 90 2308 HEX SCREW SH M3x8 (10)
 90 3306 HEX SCREW SFH M3x6 (10)
 90 3308 HEX SCREW SFH M3x8 (10)
 96 0140 NUT M4 WITH FLANGE (10)

30 6310 ANTENNA (2)

IO
 306219 SHIM 3x6x1

IO
 306219 SHIM 3x6x2

IO
 306219 SHIM 3x6x3



902308
 SH M3x8

903306
 SFH M3x6

For improved weight balance, we recommend using a narrow, light servo.

We recommend using the O-rings included with the servo to avoid unwanted chassis tweak.

Install servo using 4 identical shims of same thickness between the servo tabs and the mounting posts so the servo arms do not touch the top deck. There are 3 different thicknesses of shims.




SERVO NOT INCLUDED

FROM SERVO

TIP Tech Tip for electronics location Page 30

DETAIL



Attach servo arm to servo output shaft using screw from servo. Servo saver must be perpendicular to chassis when servo is in neutral.

! IMPORTANT!

When adjusting steering on the radio, we recommend using full steering adjustment in order to get the best steering from the car. It is important to verify that the steering block does not touch the C-hub; that would lead to chassis tweak due to extra servo strain.





7. FINAL ASSEMBLY



When installing the motor on the bulkhead, rotate the spur gear so the motor screw can be installed through a hole in the spur gear. See the detail image below.

Adjust the motor so the pinion meshes with the spur gear properly. Make sure the gear mesh is not too tight.



There should be a small amount of play between the teeth of the pinion gear and the spur gear.



Recommended:
3x2.5mm set screw
(#901302)

MOTOR
(NOT INCLUDED)


Some motors do not have a chamfer on the motor housing. If your motor does not have a chamfer on the housing and you want to use a small pinion, the motor may touch the top deck. Use a moto-tool with grinding bit or file to remove material; this will allow the motor to move more closely to the spur gear.



GEARING ADJUSTMENT



IMPORTANT!
Check page 31 before
attaching the electronics
to the chassis.




Feed the receiver wire into the antenna tube


RECEIVER
(NOT INCLUDED)

SPEED CONTROLLER
(NOT INCLUDED)


DOUBLE-SIDED TAPE
(NOT INCLUDED)



Alternate antenna location:
behind servo



Alternate antenna location:
car centerline




REAR

FRONT


7. FINAL ASSEMBLY

4x




WHEELS & TIRES & INSERTS
(NOT INCLUDED)


WARNING!
Follow the adhesive manufacturer's instructions for proper use and safety. Wear proper eye and hand protection.





960140
N M4



We recommend using #107870
HUDY Fibre Reinforced Tape



or the optional battery holders: #306163-K XRAY Graphite Battery Holder - Black
The XRAY Graphite Battery Holder can be used for LiPo as well. However, depending on the height of the LiPo batteries additional shims may have to be mounted below the stands.




DETAIL



TIP Tech tip for page 15, step 3.


When driving in high-grip conditions (carpet races), we recommend using the stands to connect the servo horn holders to the top deck. The car flex will be stiffer, making the car easier to drive. For more information, see Multi-Flex Technology™ settings below.

The stands and 3x14 screws are in the last aid bag. You must first remove the 3x5 screws from the servo horns first.



TIP Tech tip for page 27, step 2.

If there is not enough space for electronics due to a large receiver or ESC, you can cut one servo holder to create more space. If you do this, use double-sided tape to prevent servo movement.



Multi-Flex Technology™

The T3 has 4 kinds of Multi-Flex Technology™ settings: soft, soft-medium, medium-stiff, and stiff. The amount of stiffness used depends on the track surface.



SOFT - Soft setting is recommended to use on low-traction asphalt or carpet tracks. Car with this setting gives maximum traction.

However, when the traction starts to increase, we recommend changing the MFT™ setting accordingly. When you use a soft setting, even though car feels good from the beginning, after some racing time the tires overheat and then they will become difficult to drive.

SOFT-MEDIUM - By adding two screws on layshaft bulkhead, car has more steering into the corner. However, car will become a little more loose and therefore this setting is recommended when traction starts to increase.

If traction continues to increase (e.g., on carpet), change from soft-medium setting to medium-stiff setting.

MEDIUM-STIFF - When traction increases rapidly, we recommend using stands to connect servo horn stands to the top deck. This will make the car easier to drive and be more direct. However, for low-traction conditions we recommend taking them out because the car will understeer. These stands are used mainly on high-traction carpet tracks.

When the traction is very high (mainly on big races where many competitors drive), we recommend to use stiff setting to reduce the chances of tire overheating and traction rolling.

STIFF - With the stiff setting the car is easy to drive while providing enough steering to make car fast into and out of corners. The stiff setting is not recommended for low-traction conditions because the car will have not enough steering or traction.

For super-high traction when even the stiff flex setting is not enough and car is difficult to drive, we recommend checking the Set-up Book for set-up changes. For higher-traction conditions, thicker shock oil and harder springs & anti-roll bars are recommended.

For very-low traction when even the soft setting does not give enough grip and the car is too loose, we recommend checking the Set-up Book for set-up changes. For lower-traction conditions, softer shock oil, springs & anti-roll bars and more rear toe-in are recommended.

SETTING SUMMARY:

Soft setting: Technical or low-traction asphalt track



Medium-stiff setting: medium-high traction on carpet or asphalt track

Soft-medium setting: medium traction on asphalt track.

Stiff setting: Very-high traction, mainly carpet track.



SOFT SETTING

- screw not used
- screw used




SOFT-MEDIUM SETTING

- screw not used
- screw used




MEDIUM-STIFF SETTING

- screw not used
- screw used



STIFF SETTING

- screw not used
- screw used



teamxray.com

XRAY EUROPE

XRAY, K VÝSTAVISKU 6992, 91101 TRENCIN, SLOVAKIA, EUROPE
PHONE: +421-32-740 11 00, FAX: +421-32-740 11 09, info@teamxray.com

XRAY USA

RC AMERICA, 2970 BLYSTONE LANE, SUITE 109, DALLAS, 75220 TEXAS, USA
PHONE: 214-744-2400, FAX: 214-744-2401, xray@rcamerica.com

ALL RIGHTS RESERVED. © XRAY. ALL ARTWORK & DESIGN BY XRAY

