

XRAY XB8 EC

FRONT

● ■ ■ ■ APPLIED

REAR

FRONT

OFFSET

STANDARD ☐

+1 ☒

+2 ☐

STEERING BLOCK

PLASTIC ☐

ALU ☒

CAMBER LINK LOCATION: 2 1

FRONT LOWER SHOCK POSITION: 3 2 1

MEASURE UNDER ARM: full

FRONT DROOP

UPPER SHOCK POSITION: 8 7 6 5 4 3 2 1

REAR ROLL CENTER: 5 4 3 2 1

REAR LOWER SHOCK POSITION: 1 2 3

MEASURE UNDER BLOCK: full

REAR DROOP

UPRIGHT ROLL CENTER

OUTBOARD TOE-IN: 0° 2°

REAR

OFFSET

STANDARD ☐

+1 ☒

+2 ☐

OPTIONAL ALU UPRIGHT

CASTER ECCENTRIC BUSHING

LEFT = RIGHT

+2° ☒

+1° ☐

0° ☐

-1° ☐

-2° ☐

KICK-UP

LEFT = RIGHT

+2° ☒

+1° ☐

0° ☐

-1° ☐

-2° ☐

FRONT ROLL CENTER

LEFT = RIGHT

+2° ☒

+1° ☐

0° ☐

-1° ☐

-2° ☐

REAR TOE-IN

LEFT SIDE MUST BE OPPOSITE TO THE RIGHT SIDE

2° ☐

2.5° ☒

3° ☐

3.5° ☐

4° ☐

FRONT KICK-UP

LEFT = RIGHT

+2° ☒

+1° ☐

0° ☐

-1° ☐

-2° ☐

REAR KICK-UP

LEFT = RIGHT

+2° ☐

+1° ☐

0° ☐

-1° ☐

-2° ☐

WHEELBASE SHIM POSITION

FRONT ☐ REAR ☒

WING MOUNTING

LEFT = RIGHT

F3 F4 ☒

R3 R4 ☒

F1 F2 ☐

R1 R2 ☐

FRONT BRACE

PLASTIC ☒

ALU ☐

TORQUE ☐

REAR BRACE

PLASTIC ☒

ALU ☐

ANTI-SQUAT

LEFT = RIGHT

4° ☒

3° ☐

2° ☐

WING SHIM

YES ☒

NO ☐

FRONT WHEELBASE SHIM POSITION

FRONT ☐ REAR ☒

REAR WHEELBASE SHIM POSITION

FRONT ☐ REAR ☒

FRONT TOE

OUT 1.5°

IN

REAR TOE

IN

OUT

SHIM UNDER STEERING PLATE

2 mm

SERVO SAVER

TIGHT ☐

MEDIUM ☒

SOFT ☐

STEERING PLATE

STANDARD ☒

3D ☐

FRONT UPPER ARM POSITION

0mm 1mm 1mm 2mm 3mm

SHIMS BEHIND ARM

FRONT CAMBER

-3°

REAR CAMBER

-5°

FRONT RIDE HEIGHT

30 mm

REAR RIDE HEIGHT

32 mm

COMMENTS

VER. 4.0 ©XRAY